

Technical Details:

- Supports Sockets 775, 1155, 1156, 1336, 2011
- Ports: G1/4"
- LED Holes: 3mm


Box Contents:

- | | |
|------------------------|------------------|
| 1x RayStorm Waterblock | 3x Backplate |
| 1x 3mm Twin LED | 1x Thermal Paste |
| 1x Black Screw Set | |

The installation process below is shown without the tubing connected. This has been done so the installation process can be seen clearly. All watercooling components should be connected and leak tested prior to installation into a PC.



1. Select the correct backplate for your motherboards CPU socket.



2. Remove the film from the backplate stickers.



3. Place the backplate on the back of the motherboard and line up the holes. Apply pressure to secure.



4. Remove the plastic film from the base of the waterblock and apply thermal paste to the CPU.




5. Place the waterblock onto the CPU and line-up the mounting plate with the holes on the motherboard.



6. Place a spring and washers over each bolt.
Bolt >Nut >Spring >Metal washer >Plastic Washer



7. Place each of the bolts through the mounting plate and loosely screw into the backplate using the knurled section of the bolt [A]. When all 4 bolts are loosely fitted, tighten each bolt [A].



8. Use the lower knurled nut [B] to adjust the pressure on the CPU. Make sure to apply equal pressure to each spring.